

Marine diesel engines

Operator's manual

MINI-62G

MINI-74

SM-82

SM-94

SM-105L

Introduction



Introduction Presentation

Dear Customer,

First of all, we would like to thank you for choosing a Solé Diesel product. We recommend that you read this manual carefully before carrying out any of the operations and keep it close at hand, near the engine, as it can be of great use in the future.

Our goal as a manufacturing company is that you enjoy our product, regardless of the use you make of it. The equipment manufactured in Solé Diesel facilities is designed to offer the highest performance in the most demanding operating conditions.



The images, text and information contained in this manual are based on the product's features at the time of publication. Solé Diesel reserves the right to modify this document without prior notice.

Table of contents



Table of contents

	tion	
Safety pi	recautions and instructions	6
Solé Die	sel warranty	10
Section :	1 – Engine information	13
1.1.	Engine Identification	13
1.2.	Engine parts identification	14
Section 2	2 – Transport, handling and storage	15
2.1.	Reception	15
2.2.	Transport and handling the packed engine	
2.3.	Transporting and handling the unpacked Engine	16
2.4.	Storage of packed and unpacked engine	16
Section 3	3 - Installation	17
3.1.	Angle of installation	17
3.2.	Engine Installation	17
Section 4	4 - Operation	18
4.1.	Prestart checklist	18
4.2.	Cranking the engine	
4.3.	Stopping engine	
4.4.	Engine operation at low temperatures	19
4.5.	Winterization and preservation	20
4.6.	Maintenance during the storage	21
4.7.	Restoration of operational conditions	21
Section !	5 - Systems and scheduled maintenance	22
5.1.	Safety and prevention	22
5.2.	Periodic maintenance schedule	22
F 2		
5.3.	General	24
Maii	ntenance task. Screw tightening, fastening	24
Maii Maii	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection	24 24
Maii Maii	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection	24 24 25
Maii Maii Maii 5.4.	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system	24 25 25
Maii Maii Maii 5.4. Circi	ntenance task. Screw tightening, fastening	
Maii Maii Maii 5.4. Circi Oil s	ntenance task. Screw tightening, fastening	
Mair Mair Mair 5.4. Circe Oil s Mair	ntenance task. Screw tightening, fastening	
Mair Mair Mair 5.4. Circ Oil s Mair	ntenance task. Screw tightening, fastening	
Mair Mair Mair 5.4. Circ Oil s Mair	ntenance task. Screw tightening, fastening	
Mair Mair Mair 5.4. Circ Oil s Mair	ntenance task. Screw tightening, fastening	
Mair Mair 5.4. Circ Oil s Mair Mair Mair	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system uit description specifications ntenance task. Oil filter change ntenance task. Oil level check ntenance task. Oil fill/Change	
Main Main 5.4. Circu Oil s Main Main 5.5. Circu	ntenance task. Screw tightening, fastening	
Main Main Main 5.4. Circe Oil s Main Main Main 5.5. Circe Fuel Main	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system uit description specifications ntenance task. Oil filter change ntenance task. Oil level check ntenance task. Oil fill/Change. Fuel system uit description I specifications ntenance task. Fuel level inspection	
Main Main S.4. Circe Oil s Main Main Main 5.5. Circe Fuel Main	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system uit description specifications ntenance task. Oil filter change ntenance task. Oil level check ntenance task. Oil fill/Change uit description specifications ntenance task. Fuel level inspection ntenance task. Fuel level tank clean	
Main Main Main 5.4. Circu Oil s Main Main S.5. Circu Fuel Main Main	ntenance task. Screw tightening, fastening	24 24 25 26 26 26 27 28 28 28 29 29
Maii Maii 5.4. Circi Oil s Maii Maii 5.5. Circi Fuel Maii Maii	ntenance task. Screw tightening, fastening	24 25 26 26 26 26 27 28 28 28 29 29
Main Main S.4. Circe Oil s Main Main S.5. Circe Fuel Main Main Main Main Main	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system uit description specifications ntenance task. Oil filter change ntenance task. Oil filter change ntenance task. Oil fill/Change Fuel system uit description specifications ntenance task. Fuel level inspection ntenance task. Fuel tank clean ntenance task. Fuel system tenance task. Fuel tank clean ntenance task. Fuel filter change	
Main Main S.4. Circu Oil s Main Main 5.5. Circu Fuel Main Main Main Main Main Main Main	Intenance task. Screw tightening, fastening	24 24 25 26 26 26 27 28 28 28 29 29 29 29 29
Main Main S.4. Circu Oil s Main Main 5.5. Circu Fuel Main Main Main Main Main Main Main	ntenance task. Screw tightening, fastening ntenance task. Valve clearance inspection ntenance task. Compression pressure inspection Lubrication system uit description specifications ntenance task. Oil filter change ntenance task. Oil filter change ntenance task. Oil fill/Change Fuel system uit description specifications ntenance task. Fuel level inspection ntenance task. Fuel tank clean ntenance task. Fuel system tenance task. Fuel tank clean ntenance task. Fuel filter change	24 24 25 26 26 26 26 27 28 28 28 29 29 29 29 30 31

Table of contents



Coolant specifications	32
Maintenance task. Coolant check	32
Maintenance task. Coolant fill/change	32
Maintenance task. Seawater filter inspection	32
Maintenance task. Seawater pump impeller inspection	33
Maintenance task. Zinc anode inspection	33
5.7. Inlet and exhaust system	
Maintenance task. Air filter inspection	
Maintenance task. Exhaust gas, noise and vibrations inspection	
5.8. Electrical system	36
Control Panel	
Battery	36
Circuit protection	36
Relays	36
Maintenance task. Incandescent glow plug inspection	37
Maintenance task. Starter motor inspection	37
Maintenance task. Alternator belt tension inspection	
Maintenance task. Battery level	38
Section 6 - Troubleshooting	39
Section 7 - Technical specifications	44
Section 8 – Tightening torques	48
Section 9 – Wiring diagrams	50
Section 10 - Overall dimensions	53
Section 11 - Instructions to Replace and Remove	59
Section 12 - Inspection prior to the delivery of propulsion engines	61
Section 13 – Declaration of conformity for recreational Craft Propulsion Engines	63
Maintenance log	68

Safety precautions and instructions



Safety precautions and instructions

Solé Diesel is concerned for your safety and your machine's condition. Safety Precautions and Instructions are one of the primary ways to call your attention to the potential hazards associated with our engine operation. Follow the precautions listed throughout the manual before and during operation and maintenance procedures for your safety, the safety of others and the performance of your engine.

Types of Safety Precautions:

AWARNING

Indicates the presence of a hazard that can cause severe personal injuries, death or substantial property damages.

ACAUTION

Indicates the presence of a hazard that will or can cause minor personal injury or property damages.

ANOTICE

Communicates installation, operation and maintenance information that is safety related but not hazard related.

AWARNING

Servicing the fuel system and combustible materials. A flash fire can cause severe injury or death



Do not smoke or permit flames or sparks near the fuel injection system, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks.

Catch fuels in an approved container when removing the fuel line or fuel system. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines and use flexible sections to avoid fuel line breakage caused by vibrations.

Keep the compartment and the engine clean and free of debris to minimize the risk of fire.



AWARNING

Servicing the air cleaner. A sudden backfire can cause severe injury or death.

Do not operate the engine with the air cleaner/silencer removed.



Combustible materials. A fire can cause severe injury or death.



Engine fuels, fuel vapors and combustible materials are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher.

In case of fire do not open sound shield compartment and follow these instructions:

- Shut down engine(s)
- Continuously discharge entire contents of a halon or CO2 portable fire extinguisher (or other provision) immediately.

AWARNING

Carbon monoxide (CO) can cause severe nausea, fainting or death.

Safety precautions and instructions





Engine exhaust gases contains carbon monoxide gas. Carbon monoxide is an odourless, colourless, tasteless, no irritating gas that can cause death if inhaled for even a short time.

Get fresh air and do not sit, lie down or fall asleep if anyone shows signs of carbon monoxide poisoning:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles. Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision. Stomachache, vomiting, nausea.

AWARNING

Keep the area around the battery well ventilated. While the engine is running or the battery is charging, hydrogen gas is produced which can be easily ignited.



Never allow battery fluid (battery contains sulfuric acid) to come in contact with clothing, skin or eyes. Always wear safety gloves and protective clothing when servicing the battery. If battery fluid contacts the eyes and/or skin, immediately flush the affected area with a large amount of clean water and obtain prompt medical treatment.

ACAUTION



Moving parts. Keep hands, feet, hair, clothing and test leads away from the belts and pulleys when the engine is running. Replace guards, screens and covers before operating the engine.

ACAUTION

Before working on the engine or connected equipment, disable the engine as follows:



Set the engine controller to OFF position.

- (1) Disconnect the power input from battery.
- (2) Disconnect the battery cables. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Follow these precautions to prevent the starting of the engine by engine controller, remote start/stop switch, or engine start command from a remote computer.



ACAUTION

Never remove the cooler cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the cooler cap.

ANOTICE

Read the engine operator's manual and understand it before operation and maintenance of the engine, to ensure that it continues operating practices and maintenance procedures.

Hearing protection. Use to avoid hearing loss when handling the motor.

ANOTICE

- 1. The installer/operator of the engine has to wear suitable CLOTHING for the workplace and the situation; in particular, avoid loose clothes, chains, bracelets, rings and all accessories that could become entangled with moving parts.
- 2. The installer/operator of the engine has to wear personal protective equipment such as gloves, work shoes, eye and hearing protection as required by the task.
- 3. The area in which the operator is working has to be kept tidy and free of oil and other liquid spillages and solid waste (metal chips, etc.).

Safety precautions and instructions



Engine labels

A CAUTION - AVISO A

Over cranking can cause engine water ingestion.

Excesivos intentos de arranque pueden provocar entrada de agua en el motor. If the engine does not start after several attempts to crank may cause water entering the engine. In this situation it is recommended:

- 1) Close the seacock.
- 2) Drain the water from the exhaust system in the water trap.
- 3) Do not try to restart the engine until the cause of the start fail is identified.

A

AVISO



El motor y/o el inversor se suministran sin ningún fluído en su interior. Consulte el manual para seguir el procedimiento de instalación y puesta en marcha.







The engine and the gearbox are supplied without any fluid inside. Consult the manual to follow the installation procedure and commissioning as well as the fluid capacity - coolant, oil and oil of gearbox

Read the engine operator's manual and understand it before any operation and maintenance of the engine, to ensure that it continues operating practices and maintenance procedures insurance.







Moving parts. Keep hands, feet, hair, clothing and test leads away from the belts and pulleys when the engine is running. Replace guards, screens and covers before operating the engine.

Heavy Material. Engine is a heavy element, use the right tools for transportation and handling.

Do not use the motor as a step. Use it as a step can cause engine damage plus cause undesired operation.



Connection point of the battery cables to the engine. Red cable (positive) and black cable (negative).



Engine exhaust line installation label, above and below the waterline. See 5.7. Intake and exhaust system.

Solé Diesel Warranty



Solé Diesel warranty

Read the manual and documents delivered with each engine before carrying out any of the operations or presenting any queries. The engine is supplied without any liquids. Ensure that the liquids used match the specifications contained in Solé Diesel manuals.

The application of the conditions described in this document shall only be effective for engines or generator sets that have been invoiced after November 4, 2011.

Solé Diesel limited warranty

Solé Diesel guarantees that at the time of shipment all its engines and generator sets comply with the provided specifications and do not have any manufacturing defects.

The limited warranty provided by Solé Diesel enters into force from the time of sale to the firs end-purchaser or user of the engine or generator ser. In the event that the product is not immediately delivered to the end-customer, the warranty shall enter into force 6 months after the date of sale. Any limited warranty period that has not elapsed can be transferred to the following purchaser (s).

Unless authorized otherwise by Solé Diesel, the warranty periods are applied according to the time elapsed in months from the date of purchase or the limit of hours of operation (whichever occurs first) listed in the following table:

Limited Warranty Coverage Periods						
Product	Ple	Pleasure Work				
Product	Months Hours		Months	Hours		
Propulsion Engines	36	1000	12	2000		
Generators sets	36	1000	12	2000		

Solé Diesel extended warranty

Solé Diesel an extended period of coverage for the following components: engine block, cylinder head, crankshaft, camshaft, flywheel housing, timing gear housing, timing gear, conrod.

Extended Coverage Periods						
Product	Ple	asure	Work			
Product	Months	Hours	Months	Hours		
Propulsion Engines	24	1500	-	-		
Generators sets	24	1500	-	-		

Solé Diesel Warranty



Restrictions

Coverage:

- a) To validate the warranty is necessary fill and send the inspection prior to the delivery of propulsion engines or genset to Solé Diesel through an official installer. See SECTION 12.
- b) The warranty covers any failure of the product under normal opera- ting conditions caused by a defect in manufacturing.
- c) The warranty covers the labour costs necessary to replace and/or repair the defective original components, according to Solé Diesel standards of excellence. The time period covered for these operatio- ns is limited to 4 hours.
- d) The warranty covers reasonable costs of travel required to carry out the necessary operations. The travel distance is limited to 300 kilome- tres in conjunction to a travel time of 3 hours.

Excluded from coverage:

- a) If Solé Diesel products are installed and used alongside other products not designed or manufactured by Solé Diesel that affect their operation, the warranty shall apply exclusively to the Solé Diesel products and shall not apply if the products from another manufacturer are inappropriate for use alongside Solé Diesel products or are the cause of the failure or poor operation of our products.
- b) The warranty doesn't will be effective if don't filled correctly and send the inspection prior to the delivery of propulsion engines and genset to Solé through an official installer. SECTION 12.
- c) The warranty shall not apply if the revisions and maintenance services indicated in the User and Maintenance Manuals have not been adhered to properly. In case of implemented warranty, supporting document of the revisions and maintenance service should be exhibited, proving the requirements outlined in the manuals have been followed.
- d) Deterioration resulting from time of storage exceeding 6 months and/or storage conditions that do not comply with the procedures described in the User and Maintenance Manuals.
- e) Faults due to negligence, lack of service, accidents, abnormal use and inadequate service or installation.
- f) Faults due to the use of components not manufactured or sold by Solé Diesel.
- g) Faults due to electrical installations that do not comply with Solé Diesel design specifications or are not expressly approved by Solé Diesel.
- h) Faults due to the use of and operation with fuels, oils or lubricants that are not authorised by Solé Diesel.
- i) Faults due to water entering the cylinder(s) through the exhaust system.
- Faults in propulsion engines due to the use of a propeller that is inadequate for the load or application. We recommend contacting Solé Diesel to consult the choice of the correct propeller(s).
- k) Failure for general omission of the procedures described in the User and Maintenance Manuals.
- I) Components subjected to normal operating wear and tear.
- m) Costs due to phone communications, loss of time or money, discomfort, launching, grounding, removal or replacement of vessel parts or materials because the design of the vessel makes it necessary to do so to access the engine, and damage and/or accidents caused as a result of a failure.

Solé Diesel Warranty



Responsibilities

Responsibilities of the manufacturer:

The obligations of Solé Diesel are restricted to repairing the defective parts or, IF DEEMED APPROPRIATE BY SOLÉ DIESEL, returning the amount of the purchase or replacing the parts to prevent poor operation resulting from defective materials or faults in the manufacture covered by the warranty.

Solé Diesel reserves the right to modify the design of any of its products without taking on any obligation to modify a product that has been manufactured previously.

This manual, as well as technical documentation, manuals or pamphlets may undergo modifications without prior notice.

Responsibilities of the purchaser:

The purchaser shall be responsible for the care, operation and maintenance of the product in compliance with the contents of the User and Maintenance Manuals. The purchaser shall provide proof of all the maintenance services performed on the product. The costs of said services and that of the components and liquids replaced during said services shall be at the expense of the purchaser.

The maintenance operations described in this manual shall be performed during the Warranty Contract Periods (Limited and Extended Coverage) by an AUTHORISED SOLÉ DIESEL DEALER. Non-compliance with this condition shall void the warranty in all its terms. In such an event, the materials (oil, filters, etc.) and labour involved shall be at the expense of the purchaser. The purchaser should keep the invoice of the work performed as proof.

If the service is not covered by the warranty, the purchaser must pay for all labour performed, the associated materials and any other expense related to the service.

All shipments of products or components sent by the purchaser for inspection and repair shall be paid in advance by the purchaser.

After-sales service contact

Claims shall be presented during the warranty period to the nearest authorized Solé Diesel dealer (see chart of Solé Diesel Dealers), who shall take care the service covered by the warranty.

The purchaser must provide a proof of purchase and date of purchase by presenting the invoice to the authorized dealer for the purchase of the product served or a copy of it. Claims under warranty shall not be dealt with by the dealer until the date of purchase has been verified.

The following information must also be provided by the purchaser:

- a) Owner's name, address and contact telephone number.
- b) Product model and serial number.
- c) Number of service hours of the product.
- d) Detailed description of the problem.
- e) Information regarding any repair or installation performed by a service not included in the Solé Diesel distribution network, as well as the services performed.

For an updated list of our distribution network, visit Dealers section in our web page www.solediesel.com

Or request this information by contacting Solé Diesel at:

e-mail: info@solediesel.com Phone: +34 93 775 14 00

Engine information




Section 1 - Engine information

1.1. Engine Identification

Identification label:


The nameplate is located above the rocker cover.

Solé	MADE IN SPAIN	
TIPO TYPE	MINI -	
MOTOR Nº ENG No.		
kW	R.P.M.	



Engine serial number:

In addition, all engines are marked with the serial number on the block.




Engine information



1.2. Engine parts identification

PIECE	ELEMENT
1	Oil filler cap
2	Alternator
3	Cooling system
4	Cooling filler cap
5	Cooling drain plug
6	Fuel filter
7	Starter
8	Air filter

PIECE	ELEMENT
9	Oil filter
10	Oil dipstick
11	Oil drainage tube
12	Injection pump
13	Seawater pump
14	Elbow, wet exhaust
15	Silent block
16	Turbocharger



Transport, handling and storage



Section 2 - Transport, handling and storage

2.1. Reception

When the engine is delivered make sure that the packing has not been damaged during transport and that it has not been tampered with or that components inside the packing have been removed (see information marked on covers, bases and cartons).

Place the packed engine as close as possible to the place of installation and remove the packing material, checking that the goods supplied correspond to the order specifications.



If you notice damage or missing parts, inform SOLÉ S.A. after-sales departments and the carrier immediately and forward photographic evidence of the damage.

After inspecting the goods if you notice damage, write a reservation on the delivery note. Have the carrier countersign the note and advise SOLÉ S.A., preferably by mail (info@solediesel.com).

2.2. Transport and handling the packed engine

When lifting and transporting the engine use EXCLUSIVELY a forklift or bridge crane of appropriate load capacity, with chains equipped with safety hooks suitable for lifting the load.

The use of any other system automatically invalidates the insurance guarantee against possible damage to the engine.

To unpack the engine, you must follow these steps:

- 1. Remove the cardboard create.
- 2. Lift the engine using a forklift and suitable chains, which hook to the engine eyebolts.
- 3. Transfer the engine to the intended position of installation.
- 4. Remove the wooden base
- 5. Begin installation operations.




Transport, handling and storage



2.3. Transporting and handling the unpacked Engine

When the engine is unpacked and ready for transport, use EXCLUSIVELY the appropriate lifting eyebolts.



2.4. Storage of packed and unpacked engine

If the engine is left idle for prolonged periods, the client must check the possible conditions of conservation in relation to the place of storage.

If the engine is unused for prolonged periods and stored, observe all the relative technical specifications.

The treatment of the engine for storage is guaranteed for 6 months after the time of delivery.



If the user decides to start the engine after a long time period, this must be done in the presence of an authorized technician.

Installation



Section 3 - Installation

3.1. Angle of installation

Make sure the engine is installed on a level surface. Otherwise, the following angular operation maximum is permitted:

	Continuously	Temporaly
MINI-62G	15°	20° (Max. 30 min.)
MINI-74	15°	25° (Max. 30 min.)
SM-82/ SM-94	15°	25° (Max. 30 min.)
SM-105L	15°	20° (Max. 30 min.)

If the engine operates in these conditions, check Section 5.4 Lubrication System.

3.2. Engine Installation

Follow these steps to install the engine:

- 1. FIX ENGINE. See Section 10 Overall Dimensions and Section 8 Tightening torques.
- 2. ENGINE COUPLING. Couple the motor to the inverter, hydraulic pump, alternator or power extraction mechanism correctly.
- 3. CONNECT EXHAUST OUTLET. See Section 10 Overall Dimensions
 - 1. WET EXHAUST OUTLET
 - 2. DRY EXHAUST OUTLET + SEAWATER OUTLET
- 4. CONNECT SIPHON BREAKER. (if installed) See Section 10 Overall Dimensions
- 3. CONNECT SEAWATER INLET. See Section 10 Overall Dimensions
- 4. CONNECT FUEL INLET. See Section 10 Overall Dimensions
- 5. CONNECT LEAK COOLANT OUTLET. See Section 10 Overall Dimensions
- 6. FILL WITH OIL. See 5.4 Lubrication System.
- 7. FILL WITH COOLANT. See 5.6 Cooling System.
- 8. CHECK EACH PIPE CONNECTION for oil or coolant leaks.
- 9. PRIME THE FUEL SYSTEM. See 5.5 Fuel System
- 10. CONNECT TO CONTROL PANEL. See the Panel Control Operator's Manual.
- 11. CONNECT TO BATTERY. Follow label battery connection into the engine.



It is necessary to install a waterlock (supplied as accessory) in the exhaust system to avoid water ingestion (See section 5.7)

Operation



Section 4 - Operation

4.1. Prestart checklist

Follow these checks and inspections to ensure the correct engine operation. In addition, some checks require verification after unit starts.

AIR CLEANER: Check for a clean and installed air cleaner element to prevent unfiltered air from entering the engine.

AIR INLETS: Check for clean and unobstructed air inlets.

BATTERY: Check for tight battery connections.

COOLANT LEVEL: Check the coolant level according to coolant circuit capacity.

DRIVE BELTS: Check the belt condition and tension of the coolant pump and battery charging alternator belt.

EXHAUST SYSTEM: Check for exhaust leaks and blockages. Check the silencer and piping condition and check for tight exhaust system connections.

Check that the exhaust outlet is unobstructed.

FUEL LEVEL: Check the fuel level and keep the tank(s) full to ensure adequate fuel supply.

OIL LEVEL: Maintain the oil level below dipstick high mark and above dipstick low mark.

OPERATING AREA: Check for obstructions that could block the flow of admission air.

SEAWATER PUMP PRIMING: Prime the seawater pump before initial startup. To prime the pump:

- Close the seacock
- Remove the hose from the seawater-filter outlet
- Fill the hose and seawater pump with clean water
- Reconnect the hose to the water filter outlet
- Open the seacock

Confirm seawater pump operation on startup as indicated by water discharge from the exhaust outlet.

4.2. Cranking the engine

- 1. TURN ON THE KEY POSITION. To start all instruments with fuel pump.
- 2. TURN THE KEY TO PREHEATING POSITION. To heat the engine for a few seconds before the start.
- 3. TURN THE KEY TO STARTER POSITION. To feed the starter and start the engine.



If the engine doesn't start after several attempts to start, may cause water entering in the engine. See warning label on the engine.

After starting up the engine, check the following points. If you find anything wrong, immediately stop the engine, and then investigate the cause.


- 1. Lubrication oil pressure should be from 0,29 to 0,39 MPa (3 to 4 kgf/cm2) (2,9 to 3,9 bar) at nominal speed.
- 2. Coolant temperature should be 75 to 85°C.
- 3. Oil temperature should be 60 to 95°C.
- 4. Check for leakage of oil, coolant and fuel.
- 5. Knocking should die away as coolant temperature rises. No other defective noise should be heard.
- 6. Check for exhaust colour and abnormal odours.

Operation



4.3. Stopping engine

- 1. REMOVE ENGINE LOAD. Before turning off the engine, it must be freed of all charges (disengaged gearbox to neutral)
- 2. TURN THE KEY TO STOP POSITION. The key automatically returns to the OFF position. All instruments are off.
- 3. CLOSE THE SEACOCK.





If the needle of tachometer is marking counter rpm when the engine is off, turn the key back to ON and then OFF again.

4.4. Engine operation at low temperatures

Whenever the atmospheric temperature drops below zero, the following series of circumstances occur:

- The cooling liquids may freeze.
- The oil becomes thicker.
- There is a drop in the voltage at the battery terminals.
- The inlet air temperature is low and the engine has difficulty in starting.
- The fuel loses fluidity.

To prevent the damage caused by low temperature operation, the engine should be prepared:

- 1. Use special low temperature coolant or suitable anti-freezing agent concentration.
- Close the seawater cock, when the engine is stopped. Open the seawater filter cover and start the engine adding a mixture of freshwater and suitable anti-freezing agent concentration (see package labels) until the seawater circuit is filled completely. Stop the engine and replace the seawater filter cover. Before starting the engine again, open the seawater cock.
 - Repeat this operation whenever the engine is used at temperatures below 0°C.
- 3. Use oil with suitable quality and viscosity. SAE 15W40 is recommended. Under extreme conditions contact with technical support.
- 4. Cover battery with an adequate material to protect it against the cold. Check that the battery is fully charged.
 - It is also advisable to use a dielectric spray on the electrical connections.
- 5. When starting the engine, make sure that the glow plugs become hot enough.
- 6. If necessary, replace the diesel oil by a specified diesel oil type for low temperatures. The accumulation of impurities in the fuel tank could cause faulty firing.



All engines not in use are subject to rusting and corrosion of machined surfaces that are not protected with a paint coating. The degree of corrosion depends on meteorological changes and climatic conditions. The following recommendations are therefore of a general nature but they will help prevent or reduce the risk of damage due to rusting.

Operation



4.5. Winterization and preservation

If the boat is not going to be used for a long period of time or during the winter, certain tasks must be carried out to keep it in perfect operating condition. Follow the steps indicated below carefully:

- 1. Clean the outer surface of the engine.
- 2. Bleed the seawater circuit by filling it with fresh water. Fill the seawater circuit again with a mixture of fresh water and anti-freezing agent.
- 3. Remove the impeller from the seawater pump, clean it with fresh water and store it in place protected from moisture and sunlight.
- 4. Renew and refill the heat exchanger to the maximum level with a mixture of fresh water and anti-freezing agent.
- 5. Renew the oil in the engine.
- 6. Cover the air intake.
- 7. If the fuel tank is small, empty it completely and clean it; fill it up again with a mixture of diesel and anti-corrosion additive. Solé S.A. recommends DIECYL PLUS. Add one measure of this additive for every 25 liters of diesel. On the other hand, if the fuel tank is large, add 1 liter of this additive for every 500 liters of diesel.
- 8. Clean and dry the area where the engine is installed.
- 9. Loosen the belts.
- 10. Apply dielectric spray on the electrical connection, disassemble the battery and charge it several times during the time it is not being used.
- 11. Apply moisture repellent spray on the motor.

4.6. Maintenance during the storage

During the long engine storage, it has to be stored inside a ventilated area and free of humidity.

When the engine stay stopped for 3 months or more, inside parts can be oxidize and lost the oil film. As a result, the engine could to size up after the storage. To avoid this, the engine must work periodically during the storage.

Realize the following steps at least once per month:

- 1. In case that has a battery next to the engine, check the electrolyte level and fill it.
- 2. Start the engine during approximately 10 seconds.
- 3. Stop the engine during 1 minute. Repeat this action two or three times.
- 4. Be sure that oil pressure of the engine increase.
- 5. Get the engine work during 5 or 10 minutes without load, as maintenance operation.

4.7. Restoration of operational conditions

When starting up the engine again after winter lay-up, certain operations must be performed. Follow these steps:

- 1. Fill the fuel tank with clean diesel. The mixture of diesel oil and anti-corrosion additive in tank for winter lay-up can be used to operate the engine.
- 2. Check the fuel filter. If the filter is clogged, replace the filter.
- 3. Renew the oil in the engine.
- 4. Check the condition of coolant circuit's rubber hoses.
- 5. Reconnect the battery and apply a layer of neutral Vaseline to the battery terminals.
- 6. Remove the nozzle supports and clean them. If possible, verify the setting of the nozzles at a workshop. Then install the clean nozzles.
- 7. Connect the cooling and exhaust system. Open the seawater cock.
- 8. Verify whether there are any leaks in the fuel, coolant and oil systems.



Section 5 - Systems and scheduled maintenance

5.1. Safety and prevention

Information of special tools required and basic safety precautions.

Disassembly:

- ✓ Use the correct tools and instruments. Serious injury or damage to the engine can result from using the wrong tools and instruments.
- ✓ Use an overhaul stand or work bench if necessary. Also, use assembly bins to keep the engine parts in order of removal.
- ✓ Lay down disassembled or cleaned parts in the order in which they were removed. This will save you time at reassembly.
- ✓ Pay attention to the marks on assemblies, components and parts for positions or directions. Put on your own marks, if necessary, to aid reassembly.
- ✓ Carefully check each part for faults during removal or cleaning. Signs of abnormal wear will tell if parts or assemblies are functioning improperly.
- ✓ When lifting or carrying heavy parts, get someone to help you if the part is too awkward for one person to handle. Use jacks and chain blocks when necessary.

Reassembly:

- ✓ Wash all engine parts, except oil seals, O-rings, rubber seals, etc. in cleaning solvent and
 dry them.
- ✓ Use only the correct tools and instruments.
- ✓ Use only good quality lubricating oils and greases. Be sure to apply a coat of oil, grease, or sealant to parts as specified.
- \checkmark Use a torque wrench to tighten parts when specified tightening torques is required.
- ✓ Replace all gaskets and packing. Apply appropriate amount of adhesive or liquid gasket when required.



- ✓ Increase the frequency of maintenance in harsh duty conditions (frequent stops and starts, dusty surrounding, prolonged winter season, no-load running).
- ✓ Risk of burns during maintenance operations carried out when the engine is hot. Wear
 suitable safety clothing.
- $\checkmark\quad \mbox{It is strictly forbidden to clean the engine with compressed air.}$
- ✓ It is strictly forbidden to perform maintenance/cleaning operations in the presence of moving parts.
- ✓ Use gloves, overalls, etc. to protect the body from burns.

5.2. Periodic maintenance schedule

The maintenance and fault diagnostic procedures involve risks that may cause severe injury or even death. These procedures should therefore be carried out solely by qualified electrical and mechanical specialists. Before any maintenance and cleaning work, make sure that there are no moving parts that the generator housing has cooled to ambient temperature, that the electricity generating set cannot be accidentally started up and that all procedures are strictly observed.



	Intervals								
	Inspection Item	Daily	1st 20h-50h	Every 200h	Every 400h	Every 800h	Every year	Every 2 years	Winter storage and Preservation
	Screw tightening, fastening.		I		_				
	Engine block.								CL
General	Valve clearance.				ı				
	Exhaust gas, noise and vibrations.	I							
	Compression pressure.					I			
Lubrication	Genset oil.	1	С	С			С		С
system*	Oil filter.		С	С					
	Fuel level.	ı							
	Fuel tank.							CL	E/CL/I
	Fuel filter.				С				
Fuel System	Water separator filter (if applicable).		E		С				
	Injection pump.					1			
	Injector.					I			
	Purge the feed system.							I	
	Coolant.	ı						С	С
	Sea water circuit								I/CL
Cooling system	Water filter	ı	CL	CL					
Occining System	Sea water cock	1							
	Sea water pump impeller.			I/C	1				I/CL
	Anode			I/C					
Intake system	Air filter.		I		С			С	I
	Instruments.	I							
Electrical	Starter and alternator.				I				
system	Belt.		1		I	С			1
System	Battery level		I	I		С			
	Main alternator - electrical insulation.					I			1

 $[\]star$ Use oil with 15W40 viscosity and no less than ACEA E5 or API CH-4/SJ quality.

l: Inspect, adjust or fill. E: Empty. C: Change. CL: Clean.



5.3. General

Solé Diesel offers, for these engine models, the several Pack, consult on the web.

- Welcome pack.
- On board pack.
- Maintenance pack 50 hours.
- Maintenance pack 1600 hours.
- Maintenance pack 3000 hours.

Maintenance task. Screw tightening, fastening

For details of tightening torques see Section 8 Torques.

Maintenance task. Valve clearance inspection

The rocker cover must be dismounted to check the valve clearance. This operation must be carried out when the engine is cold.


Item		Assembly standard
Valve elegrance (cold cotting)	Inlet	0.25 mm
Valve clearance (cold setting)	Exhaust	0,≥5 IIIII

Inspection

 Inspect the valve clearance in the injection sequence. To check, turn the crankshaft by the specified crank angle in the normal direction to bring the piston to the top dead center of the compression stroke.


	Injection sequence	Crank angle
MINI-62G / MINI-74 SM-82 / SM-94	1 - 3 - 4 - 2	180°
SM-103	1-5-3-6-2-4	120°


- Checking Top Dead Center of No. 1 Piston on Compression Stroke. Engage the turning socket with the nut of the crankshaft pulley and turn it in the forward direction of the engine (clockwise when viewed from the front of the engine).
- Stop turning the socket at the position where the "O" mark on the outer periphery of the crankshaft pulley is aligned with the pointer on the timing gear case.
- 4. Move the rocker arms of the inlet and exhaust valves of the No. 1 cylinder up and down to check that the pushrods do not push up the rocker arms. The position where the pushrods do not push up the rocker arms of the inlet and exhaust valves (i.e., there is a clearance) is the top dead center of the No. 1 piston on the compression stroke. If the pushrods push up the rocker arms, rotate the crankshaft by another turn.
- 5. Insert a thickness gage between the rocker arm and valve cap to check the clearance.





- Loosen the lock nut. Tighten or loosen the adjusting screw, while measuring the clearance, until the thickness gage moves slightly stiff.
- 7. After adjustment, tighten the lock nut firmly. Then, check the clearance again.
- 8. Turn the crankshaft 180° or 120° clockwise. Adjust the valve clearances of other cylinders while turning the engine.







Valve clearance should be inspected and adjusted when the engine is cold.

Adjusting


- Loosen the lock nut of the adjusting screw. Adjust the clearance by turning the screw in either direction to the extent that the gauge is slightly gripped between the rocker arm and valve cap.
- 2. After adjusting the clearance, tighten the lock nut. Inspect the clearance again and make sure that it is correct.



Maintenance task. Compression pressure inspection

Start by:

- 1. Make sure the engine oil level, air cleaner, starting motor and battery are well-conditioned.
- 2. Start the engine and allow it to warm up thoroughly, until 50°C or more coolant temperature.



Measure the compression pressure on all cylinders:

- 1. Remove the injection nozzle from the cylinder head where the compression pressure is to be measured.
- 2. Attach the compression pressure gauge.
- 3. Disconnect the stop solenoid connector (the fuel supply shut off) and crank the engine by means of the starter and read the compression pressure gauge indication when the engine is running at specified speed.
- 4. If the compression pressure is lower than repair limit, check the engine parts affected.



	Engine speed	Compression pressure	Repair limit
MINI-62	150 - 200 rpm	2,94 MPa (30 kgf/cm²)	2.55 MPa (26 kgf/cm²)
MINI-74 SM-82 SM-94 SM-105L	300 rpm	2,9MPa (30 kgf/cm²)	2.6 MPa (27 kgf/cm²)



- It is not a good practice to measure the compression pressure on only few cylinders, and presume the compression on the remaining cylinders.
- Compression pressure varies with engine speed. Check engine speed when measuring the compression pressure.
- The compression pressure will be slightly higher in a new or overhauled engine due to new piston rings, valve seats, etc



5.4. Lubrication system

Circuit description


The lubrication circuit is forced by the trochoid gear pump, and it is composed of the following elements.


PIECE	ELEMENT
1	Push rod
2	Tappet
3	Relief valve
4	Oil main gallery
5	Oil pump
6	Oil strainer
7	Oil drain plug
8	Oil filter (with built-in bypass valve)
9	Crankshaft
10	Timing gear
11	Camshaft
12	Piston
13	Valve
14	Valve mechanism

PIECE	ELEMENT
1	Pushrod
2	Tappet
3	Camshaft
4	Oil main gallery
5	Ilder gear
6	Oil pump
7	Oil strainer
8	Oil pan
9	Oil filter
10	Relief valve
11	Valve mechanism
12	Piston
13	Fuel injection pump

PIECE	ELEMENT
1	Piston
2	Pushrod
3	Tappet
4	Camshaft
5	Oil main gallery
6	Idler gear
7	Oil pump
8	Oil strainer
9	Safety valve
10	Oil filter
11	Oil pan
12	Relief valve
13	Oil Cooler
14	Relief valve
15	Valve mechanism
15	Turbocharger

^{*}Including filter change (0,5I)





	Oil circuit capacity (I)*		
MINI-62G	6,5		
MINI-74	10		
SM-82 / SM-94	10		
SM-105L	12		



Oil specifications

Use oil with 15W40 viscosity (this is an all-season oil for temperatures ranging between -15°C and +40°C) or select the most suitable oil viscosity for the atmospheric temperatures on which the engine is going to be operated. On the other hand, use oil quality no less than ACEA E5/E3 or API CH-4/SJ. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.



Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.

Maintenance task. Oil filter change

The oil filter is located under inlet manifold of the engine. Remove oil filter with a belt wrench. When fitting a fresh oil filter, smear a small quantity of oil into the annular seal and firmly tighten it with the hand. When this operation is finished, start the engine and check oil is not leaking.



Maintenance task. Oil level check

Check the oil level in the crankcase daily or before each start-up to ensure that the level is between the upper (Max mark) and lower (Min mark) lines on the dipstick. To check the oil level:


- 1. Remove the dipstick
- 2. Wipe the dipstick end
- 3. Reinsert it inside the guide
- 4. Remove it again to see the oil level


If the motor is installed with an inclination, the level of the oil rods may vary. See the attached table to check the correct level of oil in the dipstick.

- H: maximum level that marks the rod
- L: minimum level that marks the rod
- E: Adjustment of the maximum level according to the inclination of the motor. It can be a positive or negative measure

A	MINI-62G	MINI-74	SM-82	SM-94	SM-105L
4 °	7,5	12,5	12,5	12,5	13
8°	16,7	35	35	35	23
12°	29	50	50	50	29
15°	37,6	57	57	57	32

Units expressed in: mm









Do not operate the engine if the oil level is below the Min mark or above the Max mark. Be careful the oil dipstick marks refer to the engine as a horizontal position. Therefore, check the engine inclination when the oil level is verified.

Maintenance task. Oil fill/Change

Oil must be changed with hot engine so as to be sure the oil is fully drained. The procedure is the following:

- 1. Drain the oil (follow steps below)
 - a. Stop the engine.
 - b. Disconnect the battery negative (-) terminal.
 - c. Remove the oil dipstick.
 - d. Connect the external oil pump to the end of the oil drain hose. Place the outlet of the pump into an oil collection container.
 - e. Allow time for the engine oil to drain completely.
- 2. Replace the oil filter
- 3. Remove external oil pump. Do not insert oil dipstick.
- 4. Fill with oil according to oil capacity circuit.
- 5. Check for leaks.
- 6. Check oil level according to the oil level check procedure.




Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage. It is important to remove the dipstick to let the air out of the engine while the engine is filled with oil, otherwise, bubbles can be create that make oil overflowing outside.

5.5. Fuel system

Circuit description

The fuel system is based on a fuel feed pump and an in-line mechanical injection pump.

PIECE	ELEMENT
1	Fuel injection Nozzle
2	Fuel injection pipe
3	Fuel return pipe
4	Injection pump
5	Feed pump
6	Fuel filter
7	Tank (Not supplied)
8	Fuel decanting filter (accessory)
9	Fuel intake pipe (accessory)



Fuel specifications

Use ASTM diesel fuel No.2-D for the best engine performance, to prevent engine damage. Never use kerosene, heavy diesel fuel or biodiesel. It is essential to use clean and filtered diesel oil.

The use of diesel oil that not complies with the technical specifications may affect warranty coverage and cause serious damage in the injection system and internal engine components.



Maintenance task. Fuel level inspection

Periodically, it is necessary to check the fuel level to assure the operation of the engine. On top of that, if fuel pump sucks air when the fuel level is lower than pump suction, it could break.

Whenever possible, keep the fuel tank full. The temperature changes may cause condensation of the damp air present in the tank and this water accumulates at the bottom. It can cause an increase of corrosion or an impossibility of starting the engine if this water is aspired by the fuel pump.

Maintenance task, Fuel tank clean

The fuel impurities could obstruct the suction pump. For this reason, drain out the content of the fuel tank to remove condensate and any foreign material. Then, wash the tank with fuel and refill it

Maintenance task. Water separator filter purge


The fuel system has to have a water separator filter (supplied as accessory) to avoid the inlet of water in the fuel circuit. According to the maintenance plan it is necessary to purge the filter to eliminate water periodically. This is the procedure:

- 1. Loosen the bottom nut to eliminate water.
- 2. Shut it off again.
- 3. Check for any leakage.

Maintenance task. Fuel filter change

Procedure to change the fuel filter:

- Remove fuel filter with a belt wrench.
- 2.
- 3. Place a new fuel filter and firmly tighten it with the hand.
- 4. Prime the system.
- 5. When this operation is finished, start the engine and check that it is not leaking.



Wash hands after any contact with diesel fuel.

Maintenance task. Injection pump inspection

The injection pump is adjusted at factory and should never be adjusted carelessly. Such adjustment, whenever is required, shall be made by a SOLÉ DIESEL licensed service shop, since a precision pump monitor and skill knowledge are required.

You must check:

- The presence of exhaust smoke color.
 Procedure: quickly accelerate engine.
 Criteria: no remarkably black smoke exhaust, and correct function of fuel cut-off solenoid
- Any leaks at the body injection pump or fuel lines.





Maintenance task. Injector inspection

To check the injection pressure of injectors (opening pressure) you have to follow these steps:

- 1. Remove nozzle and washer.
- 2. Install the injection nozzle on the tester. Slowly operate the tester handle full strokes to bleed (remove) air from the pipe and nozzle.
- Make a slow increase in pressure by operating the tester handle at a speed of more than one stroke per second while observing the pressure gauge.
- 4. The pressure gauge reading will slowly increase and, when the nozzle starts discharging fuel, it will go down fast. Take the gauge reading right then as the injection pressure.

Model	Injection pressure
MINI-62G	14,22 a 15 MPa (145 a 153kgf/cm ²)
MINI-74	18,14 a 19,12 MPa (185 a 195 kgf/cm ²)
SM-82/SM-94	18,14 a 19,12 MPa (185 a 195 kgf/cm ²)
SM-105L	18,14 a 19,12 MPa (185 a 195 kgf/cm ²)







nozzle (Reusable)


Discharge pattern for orifice with a restriction (Recondition or replace)

7. If the nozzle is bad, remove the tip from the nozzle and wash needle valve and body in clean washing solution.

And if the nozzle is still bad after the tip has been washed, replace the tip.

When installing the new tip, remove synthetic resin film from the tip and slide the needle valve in the body in clean diesel fuel to wash off inhibitor completely.

8. The washer shown on point 1 must be replaced.







When testing the injection nozzle, keep its tip pointed away from the operator. Fuel from the orifices in the tip of the nozzle is under high pressure and can cause injury to the operator.

Maintenance task. Bleeding air from the fuel system

Prime the fuel system to bleed the air from the circuit. Trapped air in the fuel system can cause difficult starting and erratic engine operation. It is necessary to prime the system:

- ✓ Before starting the engine for the first time.
- ✓ After running out of fuel and adding fuel to the tank.
- ✓ After fuel system maintenance such as changing the fuel filter, draining the fuel/water separator, or replacing a fuel system component.









For this operation you have to follow these steps:

- 1. Loosen all the injection pipes.
- 2. Start the engine to drive out air in the injection pipes and nozzles automatically.
- 3. When fuel overflows from an injection pipe, tighten it up and wait until fuel overflows from another one. Repeat it until all injection pipes are tightened.
- 4. After bleeding, clean up fuel spillage.



When fuel overflows from the injection pipes, wipe thoroughly with a cloth. Spilled fuel is a fire hazard.

5.6. Cooling system

The engine cooling system is based on coolant circulation controlled by centrifugal pump with thermostatic control and heat exchanger, where the coolant is refrigerated by sea water. Moreover, the exhaust manifold is cooled also by sea water.

COOLANT CIRCUIT DESCRIPTION

PIECE	ELEMENT		
1	Coolant pump		
2	Heat exchanger		
3	Thermostat		
3 	2 Catholic Control of the control of		

	Coolant circuit capacity (I)
MINI-62G	9,5
MINI-74	13
SM-82/SM-94	11
SM-105L	21

SEAWATER CIRCUIT DESCRIPTION

PIECE	ELEMENT
1	Bottom cock (supplied as accessory)
2	Sea water filter
3	Sea water pump
4	Heat exchanger
5	Wet exhaust elbow
(5 3 2
	Thermostatic valve
In	itial opening 76,5°C

Final opening 90°C

Coolant specifications

It is recommended use SOLÉ DIESEL 50% coolant or another coolant with similar specifications. On the other hand, distilled water with an anti-freezing agent is also suitable. The anti-freezing agent concentration according to operating conditions is specified in anti-freezing agent package labels. It is advisable select the anti-freezing agent concentration based on a temperature approx. 5°C under the actual atmospheric temperature.

Other engine coolants may affect warranty coverage, cause an internal build-up of rust and scale and/or shorten engine life.



Never mix different types of coolants. This may adversely affect the properties of the engine coolant.

Maintenance task. Coolant check


Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank, the level must be approximately 3/4 full.



Maintenance task. Coolant fill/change

- 1. Drain off all the coolant by opening the two drain plugs, one in the heat exchanger and the other in the cylinder block.
- 2. Close the drain plugs.
- 3. Refill to the hole in the tank cap with coolant.







Maintenance task. Seawater filter inspection

It is important to install a seawater filter (supplied as accessory) between seawater cock and the seawater pump to avoid that any impurity might clog the seawater circuit or seawater pump.


To clean this filter:

- 1. Loosen the wing nut.
- 2. Remove the filtering component and clean it.
- 3. Fit it again taking care that the cover is well seated on the o-ring.
- 4. Start the engine to check seawater leakages.



Seawater pump impeller is neoprene and cannot rotate dried. If operated without water, the impeller can be broken. It is important therefore that a spare impeller is always available. Impeller inspection and replacement procedure:

- 1. Close the seawater cock.
- 2. Remove the seawater pump cover plate.
- 3. Remove the impeller from the shaft.
- 4. Clean the housing.
- Inspect the impeller for damaged, cranked, broken, missing or flattened vanes. The impeller vanes should be straight and flexible.
- 6. If it is damaged replace with a new one.
- 7. Lubricate the impeller with soapy water before installation.
- 8. Install the impeller. During installation push and rotate the impeller in the same direction as the engine rotation until it is thoroughly seated in the impeller housing.
- 9. Inspect the cover plate and gasket for corrosion and/or damage. Replace components as necessary.
- 10. Lubricate the oil ring with silicon grease and attach the gasket and cover plate to the seawater pump housing.
- 11. Open the seacock.
- 12. Start the engine and check for leaks.





Maintenance task. Zinc anode inspection

In order to avoid the corrosion produced by galvanic currents, the engine is fitted with a zinc anode located on the front lid of the coolant-seawater heat exchanger. Anticorrosion zinc anode inspection and replacement:



- 1. With the engine cooled, close the seacock, open the coolant drain plug and drain the coolant into a suitable container.
- 2. Remove the anticorrosion zinc anode (plug) from the heat exchanger.
- 3. Use a wire brush to remove the loose corrosion on the anticorrosion zinc anode.
- 4. Clean the threaded hole of the heat exchanger and coat the threads of anticorrosion zinc anode. Install the anticorrosion zinc anode into the heat exchanger.
- 5. Close the coolant drain plug and open the seacock. Refill the coolant circuit.
- 6. Start the engine and check for leaks at the anticorrosion zinc anode location. The pump is operating if the seawater flows from the exhaust outlet.

5.7. Inlet and exhaust system

Exhaust circuit description

There are two possible installations of the exhaust system. You need to check the distance between water injection point and waterline to decide which type of installation you need. This information is specified in the following drawings.

The elements included in the drawing are essential for the correct engine operation:

 Waterlock (supplied as accessory) to prevent seawater from entering inside the engine when it stops.

To calculate the required collector capacity, we must follow the following formula:

C = collector capacity (L)


D = Inside diameter of the tube (mm)

L = Tube length (mm)

$$C = \frac{\left(\frac{\pi}{4}D^2 * L\right)}{1000000} * 0.5$$


- Goose neck (supplied as accessory)
- Siphon breaker (supplied as accessory) needed in case there is less than 150 mm between the water injection point of wet exhaust and the waterline, or if the point of injection is below waterline.

Type 1 installation. When between water injection point of wet exhaust and waterline is minimum 150 mm.





Type 2 installation. When between water injection point of wet exhaust and waterline there is less than 150 mm or the point of injection is below waterline.





The wet exhaust is the engine's standard equipment. If you want dry exhaust, which is an optional equipment, contact with our dealers.

Maintenance task. Air filter inspection

Engine is provided with an intake air filter. Examine the element and housing for damage (only MINI-62). Replace the complete air filter if necessary.



It is important to ensure that the combustion air is freely supplied and freely expelled from the area.

Maintenance task. Exhaust gas, noise and vibrations inspection

Inspect the exhaust system components for cranks, leaks and corrosion.

Exhaust system inspection point

- 1. Check the hoses for softness, cranks or dents. Replace the hoses as needed.
- 2. Check for corroded or broken metal parts and replace them as needed.
- 3. Check for loose, corroded or missing clamps. Tighten or replace the hose clamps and/or hangers as needed.
- 4. Check that the exhaust outlet is unobstructed.
- 5. Visually inspect the exhaust system for exhaust leaks. Check for carbon or soot residue on exhaust components. Carbon and soot residue indicate an exhaust leak. Seal leaks as needed.





5.8. Electrical system

Control Panel

You can find the all information related to the control panel in Control Panel Operator's Manual of your engine.

Sensors and switches

Coolant temperature sensor:

Operating voltage: 6-24V

Operating current: <85mA, Pmax<0.25WOperating temperature: -40°C to +120°C

Measuring range: -40°C to +120°C

Absolute max. value: 130°C, max. 1 min.

Protection: BODY IP 67Tightening torque: Max. 20Nm

Function table				
Temperature (°C)	Resistance (ohm)	Tolerance (ohm)		
40	287.4	±32.8		
60*	134	±13.5		
80	69.1	±6.5		
90*	51.2	±4.3		
100*	38.5	±3.0		
120	22.7	±2.2		

*Test point

Oil pressure sensor:

Operating voltage: 6-24V

- Operating current: >20mA, <85mA, Pmax<0.25W

Operating temperature: -20°C to +100°C

Measuring range: 0 – 10 BAR

- Absolute max. value: 30 BAR, max. 2 seconds.

Protection: BODY IP 67

- Tightening torque: Max. 20Nm

Function table			
Pressure (BAR)	Resistance (ohm)	Tolerance (ohm)	
0	10	+3/-5	
2	52	±4	
4	88	±4	
6	124	±5	
8	155	±5	
10	184	+20/-10	

Coolant temperature sensor specifications (two pole)

Operating voltage: 6-24V

Operating current: <85mA, Pmax<0.25W
 Operating temperature: -40°C to +120°C

Measuring range: -40°C to +120°C

- Absolute max. value: 130°C, max. 1 min.

- Protection: BODY IP 67

- Tightening torque: Max. 20Nm

Function table			
Temperature (°C)	Resistance (ohm)	Tolerance (ohm)	
40	287.4	±32.8	
60*	134	±13.5	
80	69.1	±6.5	
90*	51.2	±4.3	
100*	38.5	±3.0	

^{*}Test point

±2.2

120



Oil pressure sensor (two pole):

Operating voltage: 6-24V

- Operating current: >20mA, <85mA, Pmax<0.25W

- Operating temperature: -20°C to +100°C

- Measuring range: 0 - 10 BAR

- Absolute max. value: 30 BAR, max. 2 seconds.

Protection: BODY IP 67

- Tightening torque: Max. 20Nm

Function table			
Pressure (BAR)	Resistance (ohm)	Tolerance (ohm)	
0	10	+3/-5	
2	52	±4	
4	88	±4	
6	124	±5	
8	155	±5	
10	184	+20/-10	

TEMPERATURE SWITCH:

Operating voltage: 12-24VOperating power: 5W

- Operating temperature: ≤100°C ±4°C (OPEN CIRCUIT), ≥100°C±2°C (CLOSE CIRCUIT)

OIL PRESSURE SWITCH:

Operating voltage: 12VOperating power: 5W

- Operating pressure: 0.98bar (CLOSE CIRCUIT)

TEMPERATURE SWITCH (TWO POLE)

Operating voltage: 6-24VOperating power: Max 100W

Operating temperature: 96°C ±3°C (CLOSE CIRCUIT)

OIL PRESSURE SWITCH (TWO POLE):

Operating voltage: 6-24VOperating current: <0.5A

Operating pressure: 0.4bar±0.15bar (CLOSE CIRCUIT)

Battery

The minimum recommended battery capacity is 80 Ah. However, this is a general reference value since it is related to the maximum current that can offer for starting the engine.

The connection of the battery for a standard engine:

- · Positive battery is connected to the starter.
- Negative battery is connected to the relay support.

The connection of the battery for an earth isolated engine.

Positive battery is connected to the starter.



Negative battery is connected to the bipolar relay.


Circuit protection

The electrical installation of the engine has a fuse that protects all the electronics in case of overload or short circuit. It is located in the wire harness next to the starter motor.




Relays

The relays of the electrical installation are located inside the electrical protective box where it is shown in the image.




The earth isolated motors have bipolar relays, in the images can see the position.



Maintenance task. Incandescent glow plug inspection

- 1. Loosen nuts, and then remove connection plate and glow plug.
- 2. If the glow plug glows red when the positive (+) wire is connected to the portion A with the portion B grounded, the plug can be used.



Systems and scheduled maintenance



Maintenance task. Starter inspection


STARTER:

- 1. Check if there is any impurity in pinion teeth.
- 2. Make sure that the pinion shaft turns freely when turned in the direction of driving (clockwise) and it is locked when turned in the opposite direction. If not, replace the overrunning clutch.



Maintenance task. Alternator belt tension inspection

Push the belt inward with thumb pressure exerted midway between the pulleys, as shown, to check the belt tension (deflection). If the tension is incorrect, loosen the adjusting bracket bolt and mounting bolt, and move the alternator in or out.



Element Assembly Standard
V-belt deflection 10-12 mm



An excessive tension may cause a quick wear of the belt and alternator bearings. Otherwise, if the belt is excessively loose or has oil and insufficient load, it can cause the belt to skid.



Never adjust the belt tension with engine running or battery connected.

Maintenance task. Battery level

Battery requires a very careful handling and frequent checking. Proceed as shown below:

- 1. Keep battery dry and cleaned.
- 2. Check terminal cleanliness regularly. If dust is settled, terminals should be loosened, cleaned and smeared with a neutral grease layer.
- 3. Metal objects must not be placed over the battery.
- 4. Add distilled water if the level is out of range

Systems and scheduled maintenance



Section 6 - Troubleshooting

If a fault occurs in the engine, proceed as follows:

- Within the period of warranty
 - Contact to Solé Diesel Official Service. See SOLÉ DIESEL WARRANTY
- Outside the period of warranty
 - Contact to Solé Diesel Official Service. See SOLÉ DIESEL WARRANTY.
 - Stop the engine, determine the cause and repair it before continuing driving the motor.



ENGINE FAILURE	SYSTEM	PROBABLE CAUSES	RECOMMENDED ACTIONS
		Power cable fuse (red).	Replace the fuse in the installation. If fuse blows again, check electrical system for overloads or short circuits.
		Discharged or empty battery.	Charge the battery or replace it with a new one.
	ELECTRICAL SYSTEM	Loose or corroded battery connections.	Check the battery connections are correct, clean and tight.
	(CC)	Faulty start/preheating relay.	Check and replace the preheating/start relay if necessary.
		Faulty starter motor	Check starter motor and replace it if necessary.
		Control panel start signal	Check the start signal from the controller (pink wire).
		Faulty stop solenoid (ETR).	Check stop solenoid and replace it if necessary.
	GENERAL	Low compression pressure.	Check the compression of each cylinder.
	LUBRICATION SYSTEM	Oil viscosity too high.	Check oil viscosity (according to Technical Specifications).
MANUAL START	FUEL SYSTEM	Faulty or clogged fuel pump.	Check the pump by verifying the fuel inlet and outlet of the
FAILURE			pump. Replace it with a new one if necessary.
		Clogged fuel pipes	Check fuel pipes.
		Clogged fuel filter	Replace fuel filter.
		Faulty injection pump	Contact an Official Solé Diesel Service.
		Air in fuel system	Bleed fuel system.
		Dirty or faulty fuel injectors	Clean, test and/or replace fuel injector which is not operating
		Dirty of faulty fuel injectors	properly.
		Fuel injection timing malfunction	Adjust fuel injection timing
		Empty fuel tank or closed fuel valve.	Add fuel and place fuel valve in open position.
		Dirty or clogged fuel tank.	Clean tank with proper products.
	INLET AND EXHAUST SYSTEM	Dirty or clogged air filter.	Replace the air filter element.



ENGINE FAILURE	SYSTEM	PROBABLE CAUSES	RECOMMENDED ACTIONS
	GENERAL	The fuel regulator is not operational.	Contact an Official Solé Diesel Service.
		Faulty or clogged fuel pump	Check fuel pump inlet.
		Clogged fuel filter	Replace fuel filter.
	FUEL SYSTEM	Air in fuel system	Bleed fuel system.
		Incorrect injection pump setting	Contact an Official Solé Diesel Service.
		Closed fuel outlet tap	Open the fuel outlet tap.
STARTS AND THEN STOPS	COOLING SYSTEM	Low cooling liquid level.	Check cooling liquid level and fill tank if necessary.
		Faulty stop solenoid (ETR).	Check stop solenoid and replace it if necessary.
	ELECTRICAL SYSTEM	Pressed emergency stop button.	Reset the emergency stop button position.
	(CC)	Control panel start signal.	Check the start signal from the controller (yellow wire).
	INLET AND EXHAUST SYSTEM	Dirty or clogged air filter.	Replace the air filter element.
		Clogged fuel filter.	Replace fuel filter.
BLACK SMOKE	FUEL SYSTEM	Dirty or faulty fuel injectors.	Clean, test and/or replace fuel injector which is not operating properly.
BLACK SIVIUNE		Incorrect injection pump setting.	Contact an Official Solé Diesel Service.
	INLET AND EXHAUST SYSTEM	Clogged air filter.	Replace the air filter element.
	GENERAL	Incorrect valve clearance.	Perform valve adjustment.
BLUE SMOKE	LUBRICATION SYSTEM	Oil level too high.	Check the lubrication oil level and reset it.
		Faulty oil pump.	Contact our dealer
		Strangled oil pressure-relief valve.	Clean the valve and check its operation.
		Oil pressure too low.	Check oil level.
LOW OIL PRESSURE	LUBRICATION SYSTEM	Oil level too low.	Reset oil level. Inspect the engine for leaks.
		Faulty oil pressure valve.	Contact an Official Solé Diesel Service.
		Faulty pressure gauge, pressure sensor and/or	Check and/or replace elements.
		pressure switch.	
		Engine tilt above allowable values.	Check the engine installation inclination. Reinstall the engine if
		Engine the above anomable values.	necessary.



ENGINE FAILURE	SYSTEM	PROBABLE CAUSES	RECOMMENDED ACTIONS
OIL PRESSURE TOO	LUBRICATION SYSTEM	Strangled oil pressure-relief valve Faulty oil pressure valve Oil level too high. Obstruction of oil lines.	Clean the valve and check its operation. Contact an Official Solé Diesel Service. Reset oil level. Contact an Official Solé Diesel Service.
HIGH FUEL	GENERAL	Low compression pressure. Electrical overload. The regulator is not working properly.	Check compression. Reduce electrical load. Contact an Official Solé Diesel Service.
CONSUMPTION	FUEL SYSTEM INLET AND EXHAUST SYSTEM	Fuel injection timing malfunction. Clogged air filter	Adjust fuel injection timing Replace the air filter element.
	GENERAL	Incorrect valve clearance.	Perform valve adjustment.
100/200/50	FUEL SYSTEM	Clogged fuel filter. Dirty or faulty fuel injectors.	Replace fuel filter. Clean, test and/or replace fuel injector which is not operating properly. Clean fuel system with proper products. Inspect the source of
LOW POWER		Water in fuel system. Fuel injection timing malfunction.	the water inlet. Adjust fuel injection timing
	INLET AND EXHAUST SYSTEM	Clogged air filter Exhaust detonations	Replace the air filter element. Inspect exhaust system. Replace exhaust system components that are not operational.
	GENERAL	Low compression pressure. Electrical overload.	Check compression. Reduce electrical load.
ENGINE OVER HEATING	LUBRICATION SYSTEM	Faulty oil pump. Oil viscosity too high. Oil level too low.	Contact an Official Solé Diesel Service. Check oil specifications according to Technical Specifications. Reset oil level. Inspect the engine for leaks.



ENGINE FAILURE	SYSTEM	PROBABLE CAUSES	RECOMMENDED ACTIONS	
		Faulty coolant water pump.	Check coolant pump (impeller, pump sealing).	
		Plugged or restricted-pitch salt water tap.	Clean the tap, check if the salt water pump impeller is damaged.	
	COOLING SYSTEM	Faulty salt water pump.	Check sea water pump (impeller, pump sealing).	
ENGINE OVER HEATING		Clogged water cooler.	Clean the water cooler.	
		Low coolant level.	Restore normal coolant level for operation.	
		Thermostat is not operational.	Replace the thermostat.	
	INLET AND EXHAUST SYSTEM	Clogged air filter	Replace the air filter element.	
		Discharged or empty battery.	Charge the battery or replace it with a new one.	
FAULTY BATTERY	ELECTRICAL SYSTEM	Loose or corroded battery connections.	Check the battery connections are correct, clean and tight.	
CHARGE	(DC)	Faulty DC alternator regulator.	Replace alternator.	
		DC alternator belt tension.	Check belt tension and change if necessary.	

Technical specifications



Section 7 - Technical specifications

MINI-62G



Specifications			
No. Of Strokes:	4	Number of cylinders:	4
Layout of cylinders:	In line	Cylinder diameter (mm):	88
Stroke (mm):	95	Total displacement (cc):	2311
Compression ratio:	22:1	Continuous power (kW):	23,1
ntermittent Power (kW):	25,7	Max RPM:	1700
Rotation (viewed from flywheel side):	Counterclockwise	Idle RPM:	800 (±50)
Intake system:	Naturally aspirated	Starting aid:	Glow plugs

Electrical system			
Voltage (V):	12	Alternator (A):	95
Minimum Battery Capacity (Ah):	92	Engine shut off system:	ETR
Battery Cable Length (m):	1,5 m	Battery Cable Section (mm2):	70 mm2

Fuel system			
Fuel type:	Diesel	Injection system:	Mechanical and indirect
Fuel standards:	Fueloil diesel ASTM	Injection pump type:	Rotative
Maximum suction head (m):	0,6	Governor type:	Mechanical
Injection Pressure (bar):	140	Maximum static head of return pipe (bar):	0,26
Firing order:	1-3-4-2	Injection timing (°):	8 Before TDC
Idle Consumption (g/kWh):	300	Consumption at 50 % (g/kWh):	280
Consumption At 75 % (g/kWh):	263	Consumption at 100 % (g/kWh):	265

Lubrication system			
Lubrication type:	Forced circulation	Oil consumption at full load (g/kWh):	7,95
Minimum pressure at maximum RPM (kg/cm2):	2	Maximum pressure at maximum RPM (kg/cm2):	4
Minimum pressure at idle (kg/cm2):	1	Oil type:	SAE 15W40
Maixmum oil temperature (°C):	79	Oil pan capacity (I):	5,5
Total circuit capacity (I):	6,5	Oil pressure switch (kg/cm2):	0,5

Cooling system			
Coolant type:	Organic 50%, -38°C	Volume capacity of coolant circuit (I):	9,5
Coolant pump flow at maximum RPM (I/min):	102	Sea water pump flow at maximum RPM (I/min):	75 *
Maximum suction head of sea water (m):	4,5	Thermostat valve starts opening (°C):	76,5
Thermostat valve completely opened (°C):	90	Maximum sea water temperature (°C):	32
Heat to be extracted at 100 % load (kcal/h):	33989,87	Engine ratio/coolant pump RPM:	0,81

Installation data / Dimensions			
Sea water hose inner diameter (mm):	32	Fuel feeding hose inner diameter (mm):	8
Fuel return hose inner diameter (mm):	6	Exhaust hose inner diameter (mm):	60**
Total length (mm):	640	Total width (mm):	517
Total height (mm):	623	Down Angle (RO):	15
Max. Intermittent inclination in operation (°):	20		

^{*} The sea water pump flow has been obtained under zero aspiration height conditions. Besides, depending on the arrangement of the complete system (hoses, elbows, suction heads, etc.) this value can be lower.

^{**} The diameter system will be calculated depending on each installation in case of a dry exhaust

MINI-74



Specifications			
No. Of Strokes:	4	Number of cylinders:	4
Layout of cylinders:	In line	Cylinder diameter (mm):	94
Stroke (mm):	120	Total displacement (cc):	3331
Compression ratio:	22:1	Continuous power (kW):	42,3
Intermittent Power (kW):	47	Max RPM:	2500
Rotation (viewed from flywheel side):	Counterclockwise	Idle RPM:	800 (±50)
Intake system:	Naturally aspirated	Starting aid:	Glow plugs

Electrical system			
Voltage (V):	12	Alternator (A):	95
Minimum Battery Capacity (Ah):	92	Engine shut off system:	ETS
Battery Cable Length (m):	1,5 m	Battery Cable Section (mm2):	70 mm2

Fuel system			
Fuel type:	Diesel	Injection system:	Mechanical and indirect
Fuel standards:	Fueloil diesel ASTM	Injection pump type:	In line
Maximum suction head (m):	0,6	Governor type:	Mechanical
Injection Pressure (bar):	116	Maximum static head of return pipe (bar):	N/A
Firing order:	1-3-4-2	Injection timing (°):	22 Before TDC
Idle Consumption (g/kWh):	240	Consumption at 50 % (g/kWh):	228
Consumption At 75 % (g/kWh):	229	Consumption at 100 % (g/kWh):	233

Lubrication system			
Lubrication type:	Forced circulation	Oil consumption at full load (g/kWh):	N/A
Minimum pressure at maximum RPM (kg/cm2):	3	Maximum pressure at maximum RPM (kg/cm2):	5
Minimum pressure at idle (kg/cm2):	1	Oil type:	SAE 15W40
Maixmum oil temperature (°C):	90	Oil pan capacity (I):	9
Total circuit capacity (I):	10	Oil pressure switch (kg/cm2):	0,5

Cooling system			
Coolant type:	Organic 50%, -38°C	Volume capacity of coolant circuit (I):	13
Coolant pump flow at maximum RPM (I/min):	190	Sea water pump flow at maximum RPM (I/min):	62,5 *
Maximum suction head of sea water (m):	4	Thermostat valve starts opening (°C):	76,5
Thermostat valve completely opened (°C):	90	Maximum sea water temperature (°C):	32
Heat to be extracted at 100 % load (kcal/h):	38271,92	Engine ratio/coolant pump RPM:	0,72

Installation data / Dimensions			
Sea water hose inner diameter (mm):	32	Fuel feeding hose inner diameter (mm):	8
Fuel return hose inner diameter (mm):	-	Exhaust hose inner diameter (mm):	75**
Total length (mm):	714	Total width (mm):	527
Total height (mm):	710	Down Angle (R0):	15
Max. Intermittent inclination in operation (°):	25		

^{*} The sea water pump flow has been obtained under zero aspiration height conditions. Besides, depending on the arrangement of the complete system (hoses, elbows, suction heads, etc.) this value can be lower.

^{**} The diameter system will be calculated depending on each installation in case of a dry exhaust

SM-82



Specifications			
No. Of Strokes:	4	Number of cylinders:	4
Layout of cylinders:	In line	Cylinder diameter (mm):	94
Stroke (mm):	120	Total displacement (cc):	3331
Compression ratio:	19.5:1	Continuous power (kW):	54,3
Intermittent Power (kW):	60,3	Max RPM:	2500
Rotation (viewed from flywheel side):	Counterclockwise	Idle RPM:	850 (±50)
Intake system:	Turbocharged	Starting aid:	Glow plugs

Electrical system			
Voltage (V):	12	Alternator (A):	95
Minimum Battery Capacity (Ah):	92	Engine shut off system:	ETR
Battery Cable Length (m):	1,5 m	Battery Cable Section (mm2):	70 mm2

Fuel system			
Fuel type:	Diesel	Injection system:	Mechanical and direct
Fuel standards:	Fueloil diesel ASTM	Injection pump type:	Rotative
Maximum suction head (m):	0,6	Governor type:	Mechanical
Injection Pressure (bar):	180	Maximum static head of return pipe (bar):	N/A
Firing order:	1-3-4-2	Injection timing (°):	5 Before TDC
Idle Consumption (g/kWh):	260	Consumption at 50 % (g/kWh):	247
Consumption At 75 % (g/kWh):	240	Consumption at 100 % (g/kWh):	255

Lubrication system			
Lubrication type:	Forced circulation	Oil consumption at full load (g/kWh):	7,65
Minimum pressure at maximum RPM (kg/cm2):	3	Maximum pressure at maximum RPM (kg/cm2):	5
Minimum pressure at idle (kg/cm2):	1	Oil type:	SAE 15W40
Maixmum oil temperature (°C):	87	Oil pan capacity (I):	9
Total circuit capacity (I):	10	Oil pressure switch (kg/cm2):	0,5

Cooling system			
Coolant type:	Organic 50%, -38°C	Volume capacity of coolant circuit (I):	11
Coolant pump flow at maximum RPM (I/min):	190	Sea water pump flow at maximum RPM (I/min):	62,5 *
Maximum suction head of sea water (m):	4	Thermostat valve starts opening (°C):	76,5
Thermostat valve completely opened (°C):	90	Maximum sea water temperature (°C):	32
Heat to be extracted at 100 % load (kcal/h):	43989,93	Engine ratio/coolant pump RPM:	0,72

Installation data / Dimensions			
Sea water hose inner diameter (mm):	32	Fuel feeding hose inner diameter (mm):	8
Fuel return hose inner diameter (mm):	8	Exhaust hose inner diameter (mm):	75**
Total length (mm):	714	Total width (mm):	566
Total height (mm):	821	Down Angle (R0):	15
Max. Intermittent inclination in operation (°):	25		

^{*} The sea water pump flow has been obtained under zero aspiration height conditions. Besides, depending on the arrangement of the complete system (hoses, elbows, suction heads, etc.) this value can be lower.

^{**} The diameter system will be calculated depending on each installation in case of a dry exhaust

SM-94



Specifications			
No. Of Strokes:	4	Number of cylinders:	4
Layout of cylinders:	In line	Cylinder diameter (mm):	94
Stroke (mm):	120	Total displacement (cc):	3331
Compression ratio:	19:1	Continuous power (kW):	62,1
Intermittent Power (kW):	69	Max RPM:	2500
Rotation (viewed from flywheel side):	Counterclockwise	Idle RPM:	850 (±50)
Intake system:	Turbocharged	Starting aid:	Glow plugs

Electrical system			
Voltage (V):	12	Alternator (A):	95
Minimum Battery Capacity (Ah):	95	Engine shut off system:	ETR
Battery Cable Length (m):	1,5 m	Battery Cable Section (mm2):	70 mm2

Fuel system			
Fuel type:	Diesel	Injection system:	Mechanical and direct
Fuel standards:	Fueloil diesel ASTM	Injection pump type:	Rotative
Maximum suction head (m):	0,6	Governor type:	Mechanical
Injection Pressure (bar):	180	Maximum static head of return pipe (bar):	N/A
Firing order:	1-3-4-2	Injection timing (°):	5 Before TDC
Idle Consumption (g/kWh):	250	Consumption at 50 % (g/kWh):	238
Consumption At 75 % (g/kWh):	235	Consumption at 100 % (g/kWh):	250

Lubrication system			
Lubrication type:	Forced circulation	Oil consumption at full load (g/kWh):	7,5
Minimum pressure at maximum RPM (kg/cm2):	3	Maximum pressure at maximum RPM (kg/cm2):	5
Minimum pressure at idle (kg/cm2):	1	Oil type:	SAE 15W40
Maixmum oil temperature (°C):	89	Oil pan capacity (I):	9
Total circuit capacity (I):	10	Oil pressure switch (kg/cm2):	0,5

Cooling system			
Coolant type:	Organic 50%, -38°C	Volume capacity of coolant circuit (I):	11
Coolant pump flow at maximum RPM (I/min):	190	Sea water pump flow at maximum RPM (I/min):	62,5 *
Maximum suction head of sea water (m):	4	Thermostat valve starts opening (°C):	76,5
Thermostat valve completely opened (°C):	90	Maximum sea water temperature (°C):	32
Heat to be extracted at 100 % load (kcal/h):	43989,93	Engine ratio/coolant pump RPM:	0,72

Installation data / Dimensions			
Sea water hose inner diameter (mm):	32	Fuel feeding hose inner diameter (mm):	8
Fuel return hose inner diameter (mm):	8	Exhaust hose inner diameter (mm):	75**
Total length (mm):	714	Total width (mm):	614
Total height (mm):	810	Down Angle (RO):	15
Max. Intermittent inclination in operation (°):	25		

^{*} The sea water pump flow has been obtained under zero aspiration height conditions. Besides, depending on the arrangement of the complete system (hoses, elbows, suction heads, etc.) this value can be lower.

^{**} The diameter system will be calculated depending on each installation in case of a dry exhaust

SM-105L



Specifications			
No. Of Strokes:	4	Number of cylinders:	6
Layout of cylinders:	In line	Cylinder diameter (mm):	94
Stroke (mm):	120	Total displacement (cc):	4996
Compression ratio:	22:1	Continuous power (kW):	50,4
Intermittent Power (kW):	56	Max RPM:	2300
Rotation (viewed from flywheel side):	Counterclockwise	Idle RPM:	800 (±50)
Intake system:	Turbocharged with inte	erco Starting aid:	Glow plugs

Electrical system			
Voltage (V):	12	Alternator (A):	95
Minimum Battery Capacity (Ah):	99	Engine shut off system:	ETS
Battery Cable Length (m):	1,5 m	Battery Cable Section (mm2):	70 mm2

Fuel system			
Fuel type:	Diesel	Injection system:	Mechanical and indirect
Fuel standards:	Fueloil diesel ASTM	Injection pump type:	In line
Maximum suction head (m):	0,6	Governor type:	Mechanical
Injection Pressure (bar):	130,1	Maximum static head of return pipe (bar):	N/A
Firing order:	1-5-3-6-2-4	Injection timing (°):	21 Before TDC
Idle Consumption (g/kWh):	245	Consumption at 50 % (g/kWh):	260,28
Consumption At 75 % (g/kWh):	252,69	Consumption at 100 % (g/kWh):	260,28

Lubrication system			
Lubrication type:	Forced circulation	Oil consumption at full load (g/kWh):	N/A
Minimum pressure at maximum RPM (kg/cm2):	2	Maximum pressure at maximum RPM (kg/cm2):	4
Minimum pressure at idle (kg/cm2):	1	Oil type:	SAE 15W40
Maixmum oil temperature (°C):	96	Oil pan capacity (I):	11
Total circuit capacity (I):	12	Oil pressure switch (kg/cm2):	0,5

Cooling system			
Coolant type:	Organic 50%, -38°C	Volume capacity of coolant circuit (I):	21
Coolant pump flow at maximum RPM (I/min):	155	Sea water pump flow at maximum RPM (I/min):	62,5 *
Maximum suction head of sea water (m):	4	Thermostat valve starts opening (°C):	76,5
Thermostat valve completely opened (°C):	90	Maximum sea water temperature (°C):	32
Heat to be extracted at 100 % load (kcal/h):	58555,79	Engine ratio/coolant pump RPM:	0,73

Installation data / Dimensions			
Sea water hose inner diameter (mm):	32	Fuel feeding hose inner diameter (mm):	8
Fuel return hose inner diameter (mm):	-	Exhaust hose inner diameter (mm):	75**
Total length (mm):	928	Total width (mm):	563
Total height (mm):	748	Down Angle (RO):	15
Max. Intermittent inclination in operation (°):	20		

^{*} The sea water pump flow has been obtained under zero aspiration height conditions. Besides, depending on the arrangement of the complete system (hoses, elbows, suction heads, etc.) this value can be lower.

^{**} The diameter system will be calculated depending on each installation in case of a dry exhaust

Tightening torques



Section 8 – Tightening torques

Important nuts and screws:

TIGHTENING VALUES	Dia. x pitch of the thread		MII	NI-62G		
	(M thread)	N	-m	k	gf-m	
Cylinder head	M12 x 1.75	118	3 ± 5	12.	0.5 ± 0.5	
Rocker cover	M8 x 1.25	12	! ± 1	1.2	± 0.1	
Rocker arm shaft bracket (long bolt)	M8 x 1.25	15	± 2	1.5	± 0.2	
Main bearing cap	M12 x 1.75	83	± 5	8.5	± 0.5	
Connecting rod cap nut	M10 x 1	54	· ± 5	5.5	.5 ± 0.5	
Flywheel	M12 x 1.25	83	± 5	8.5	± 0.5	
Camshaft thrust plate	M8 x 1.25	12	! ± 1	1.2	± 0.1	
Front plate	M8 x 1.25	12	! ± 1	1.2	± 0.1	
Timing gear case cover	M8 x 1.25	12	! ± 1	1.2	± 0.1	
Crankshaft pulley	M24 x 1.5	392	± 10	40	0 ± 1	
Flywheel housing	M10 x 1.25	60	± 6	6.1	± 0.6	
Oil pan	M8 x 1.25	7.8	3 ± 1	0.8	± 0.1	
Oil pan drain plug	M14 x 1.5	39	± 4	4.0	± 0.4	
Oil filter shaft	M20 x 1.5	49	± 5	5.0	.0 ± 0.5	
Oil filter	M20 x 1.5	12	! ± 1	1.2	2 ± 0.1	
Fuel injection nozzle	M20 x 1.5	59	± 6	6.0	± 0.6	
Fuel injection nozzle retaining nut	M16 x 0.75	37	± 2.5	3.77	± 0.25	
Fuel leak off pipe	M12 x 1.5	23	± 2	2.3	± 0.2	
Fuel injection pump gear	M12 x 1.75	64	· ± 5	6.5	± 0.5	
Starter engine terminal B	M8 x 1.25	11	. ± 1	1.1	± 0.1	
Glow plug (body)	M10 x 1.25	18	3 ± 2	1.8	± 0.2	
Exhaust manifold	M8 x 1.25	30	± 2	3.1	± 0.3	
Pressure relief valve	M22 x 1.5	49	± 5	5.0	± 0.5	
Fuel injection pipe	M12 x 1.5	29	± 3	3.0	± 0.3	
Fuel return pipe	M10 x 1.25	20	± 2	2.0	± 0.2	
Oil pump set bolt	M12 x 1.75	34	± 4	3.5	± 0.4	
Overheating warning unit (temperature switch)	M16 x 1.5	23	23 ± 2 2.3 ±		± 0.2	
Drain bolt	M16 x 1.5	44	± 5	4.5	± 0.5	
		4	₽T		7T	
		N-m	kgf-m	N-m	kgf∙m	
General tightening torque	M6 x 1.0	4 ± 1	0.4 ± 0.1	9 ± 1	0.9 ± 0.1	
denotal agricining torque	M8 x 1.25	12 ± 1	1.2 ± 0.1	18 ± 3	1.85 ± 0.35	
	M10 x 1.25	22 ± 3	2.2 ± 0.3	35 ± 6	3.6 ± 0.6	
	M12 x 1.25	35 ± 6	3.6 ± 0.6	64 ± 10	6.5 ± 1	

Tightening torques





TIGHTENING VALUES	Dia. x pitch of the thread	MINI-74 / SM-82 SM-94 / SM-105L				
	(M thread)	N-m		kgf-	m	
Cylinder head	M12 x 1.75	113 a	123	11.5 a	12.5	
Rocker cover	M8 x 1.25	10.0 a	13.0	1.0 a	1.3	
Rocker arm shaft brackets	M8 x 1.25	10.0 a	20.0	1.0 a	2.0	
Main bearing caps	M14 x 2	98 a 1	L08	10.0 a	11.0	
Connecting rod cap nut	M10 x 1.25	49.0 a	59.0	5.0 a	6.0	
Flywheel	M12 x 1.25	78.5 a 8	88.3	8.0 a	9.0	
Camshaft thrust plate	M8 x 1.25	10.0 a	13.0	1.0 a	1.3	
Front plate	M8 x 1.25	10.0 a	13.0	1.0 a	1.3	
Timing gear case cover	M8 x 1.25	10.0 a	13.0	1.0 a	1.3	
Crankshaft pulley	M30 x 1.5	480 a !	500	49 a	51	
Idler gear thrust plate	M10 x 1.25	29.0 a 3	39.0	3.0 a 4.0		
Oil pan	M8 x 1.25	10.0 a 13.0		1.0 a 1.3		
Oil pan drain plug	M14 x 1.5	34.0 a	44.0	3.5 a 4.5 7	3.5 a 4.5 7.5 a 8.5	
Fuel leak off pipe nut	M12 x 1.5	20.6 a 2	24.5	2.1 a 2.5		
Fuel injection pump gear nut	M14 x 1.5	83.4 a 9	98.0	8.5 a 10.0		
Glow plug	M12 x 1.25	20.0 a 3	30.0	2.0 a 3.0		
Exhaust manifold	M8 x 1.25	15.0 a :	22.0	1.5 a	2.2	
Oil pressure-limiting valve	M22 x 1.5	44.1 a	53.9	4.5 a	5.5	
Fuel injection tube nuts	M12 x 1.5	26.5 a 3	32.4	2.7 a	3.3	
Fuel return tube nuts	M10 x 1.25	17.7 a :	21.6	1.8 a	2.2	
Oil pump gear	M10 x 1.25	28.0 a 3	38.0	2.9 a	3.9	
Starter engine terminal B	M8 x 1.25	9.81 a	11.8	1.0 a	1.2	
Balancer	M8 x 1.25	27.5 a 3	33.4	2.8 a	3.4	
Fuel injection pump bolt	M14 x 1.5	15.0 a :	20.0	1.5 a	2.0	
Oil level sensor	1- 1/ 16- 12	49.0 a 58.8		5.0 a	6.0	
	,	4T		7T		
		N-m	kgf-m	N∙m	kgf-m	
General tightening torque	M6 x 1.0	2.94 a 4.90	0.3 a 0.5	7.89 a 9.80	0.8 a 1.0	
	M8 x 1.25			14.7 a 21.6		
	M10 x 1.25			29.4 a 41.2		
	M12 x 1.25	29.4 a 41.2	3.0 a 4.2	53.9 a 73.5	5.5 a 7.5	


Wiring diagrams




Section 9 - Wiring diagrams











Overall dimensions




Section 10 – Overall dimensions





Supensor/Engine Mount



BRIDA INVERSOR/COUPLING GEARBOX


DATOS TÉCNICOS — TECHNICAL DATA


Manguera agua salada / Sea water hose = Ø32 mm Manguera entrada combustible/ Fuel hose inlet = Ø8 mm Manguera retorno combustible / Fuel hose oulet = Ø6 mm

MOTOR MINI-62/G INV.TM-93 2,09:1 MINI-62/G ENGINE TM-93 2.09:1




	/						
MATERIAL		TRATA	MIENTO	ACABADO	PRESEN	NTACION	ESCALA
					SUAVIZAR A	ARISTAS VIVAS	-/-
DIBUJADO	VERIFICA	.DO	TOL.GENERAL	FECHA CRE	ACION	ULTIMA	REVISION
D. Flavià				25-05-20	017		
501	L]£	3, 8	3. A .	17	130	483.	. 1 G





Detalle/Detail A





Supensor/Engine Mount


DATOS TÉCNICOS / TECHNICAL DATA


Manguera agua salada/ Sea water hose: Ø32mm Manguera entrada combustible / Fuel hose intake: Ø8mm

MOTOR M	MOTOR MINI-74 INV. TM-345 2,00:1								
MINI-74 ENGINE & GEARBOX TM-345 2,00:1									
MATERIALACABADOTRATAMIENTO PRESENTACIÓN ESCALA ./.									
DIBUJADO VEI J.RODRÍGUEZ	RIFIÇADO	GRĄDO PRECISIÓN	FECHA CREA 15/05/201		ÚLTIMA R 10/0	EVISIÓN . 5/2016			
Sole Diesel	SOL	É, S.A.	1743	3448	33	Α			









DATOS TÉCNICOS - TECHNICAL DATA

Entrada agua refrig. / Raw water inlet = Ø32mm Entrada Gasoil / Fuel inlet = Ø8mm

MOTOR SM-82 INV. TM-345 2,00:1


SM-82 ENGINE TM-345 2.00:1 GBOX.


CIVI CZ				0 2.00.		<i>γ</i> Ο/\.	
MATERIA	۱ <u>ـ</u>	<i>P</i>	CABADO	TRATAMIENTO PRESE		NTACIÓN	ESCALA
							./.
DIBUJADO	VERIF	ICADO	GRADO PRECISIÓN	FECHA CREA	CIÓN	ÚLŢIMA F	REVISIÓN
XAVIER S.UBACH MEDIO		09/03/201	6				
201 É 2 A				4700	4.40		





SOLÉ, S.A.

17834483











DATOS TÉCNICOS (TECHNICAL DATA)


Manguera agua salada *(Sea water hose)*: Ø32mm Manguera entrada combustible *(Fuel hose inlet)*: Ø8mm


Especificaciones del producto pueden ser modificadas sin previo aviso (Product specifications are subject to change without notice)

MOTOR SM-94 INV. TM-345 2,00:1									
SM-94 ENGINE & TM-345 GBOX 2,00:1									
MAŢĘŖI <i>Ą</i>	۸Ļ	^	CABADO	ŢŖĄŢĄMĮĘŊŢŌ	PŖĘŞE	ŊŢĄĊĮŎŊ	. ESCALA ./.		
DIBUJADO JOSE	. VERIF	IÇĄDQ	GRADO PRECISIÓN	FECHA CREA 30/10/2017		ÚLŢIMA.R 	EVISIÓN .		
Solé Dies	٩	SOL	.É, S.A.	1793	344	83			











Suspensor (Engine Mount): 61665200 Carga/Load: 300KG, Dureza/Hardness: 65 Sh A (Opcional/Optional)

BRIDA INVERSOR COUPLING GEARBOX





DATOS TÉCNICOS - TECHNICAL DATA

- (1) Entrada agua salada / Sea water inlet. Use water hose Ø32mm
- (2) Manguera entrada combustible / Fuel hose inlet = \$8 mm.

MOTOR SM-105/L CON INV. TM-93 2,77:1								
SM-105/L ENG	INE TM				ô	AUTODES		
MATERIAL		TRACTAME	NT	ACABAT	PRESENTAC	CIÓ	ESC	Al A
10011000		110101741121	<u> </u>			ristas vivas		-/-
DIBUIXAT	VERIF	ICAT	Tol. GENERAL	DATA CRE	ACIÓ	ULTIMA	RE	visió
XAVIER	S. UE	ACH		11/05/2	017			
	175	30485	5L					

Instructions to Replace and Remove



Section 11 - Instructions to Replace and Remove

When you decide to replace the engine, please contact SOLÉ S.A.; will provide relevant instructions regarding the laws in force at the time. When disposing of the whole or parts of this engine, meets LAWS IN FORCE IN THE COUNTRY OF INSTALLATION.

For more information about the materials they are made of the individual components of the engine, contact SOLÉ S.A.

Instructions to Replace and Remove



Inspection prior to the Gold Diesel delivery of propulsion engines

Section 12 - Inspection prior to the delivery of propulsion engines

INSPECTION PRICE	R TO THE DELIVER	RY OF PRO	OPULSION	I ENGINE	S			
Installer / Marina i	nformation							
Installer Company:			Installation	Date:				
Contact Tel. no.:			E-mail:					
Owner's Informatio	n							
Name and surnames:								
Contact Tel. no.:			Email:					
Ingine Information								
Engine model:								
Engine serial number:		Gearbox / S	Saildrive sei	rial nº.:				
Installation Informa	ntion							
Machine chamber ope	rating temperature:						°C	
Angle of the engine (bo	at moored):						0	
Maximum angle of the	engine (navigation con-	ditions):					0	
Is the wet exhaust ebo	w above or below the fl	oating line?			above		below	
Propulsion Line Info	ormation							
Boat model:			Gearbox / S	Saildrive transmission ratio:				
Shaft diameter:	1	mm	Shaft lengt	h:			mm	
Propeller diameter:	itch:		mm/inches	Nº. Of prope blades:	eller			
Exhaus, Cooling an	d Fuel Line Informa	tion						
Int. Diameter of exhaus	st hose:	mm	Int. Diamet	er of sea wa	ater intake to	o the		
Int. Diameter of diesel	intake:	mm	pump:	mi				
Int. Diameter of diesel	return intake:	mm					•	
Has an exhaust collect	or been installed?	YES	Uae an air t	trap been in	ctalled2		YES	
rias ari extraust conect	or been installed:	N0	rias air air i	uap been in	stalled:		N0	
Verifications Prior 1	to Start-Up			V/x		Notes		
Correct engine alignme	ent.							
Electrical installation of	onnections.				1			
Engine oil level.					1			
Gearbox oil level.]			
Coolant level and conc	entration.							
Control lever operation								
Transmissions belts an	d belt tension.							
Airtight sea water cock								
Verification of Engi	ne No-Load Operati		V/x		Notes			
Unusual noises from th	e transmission.							
Oil pressure]			
Bleed the fresh water of]			
	anel: normal indication	operation.						
Water, oil and fuel leak	s in the engine or trans							

Inspection prior to the Gold Diesel delivery of propulsion engines

INSPECTION PRIOR TO THE DELIVERY OF PROPULSION ENGINES Verification of Motor Operating with Propeller Load Notes V/x Verify maximum engine rpm at full load and with forward gear clutched. This test should be performed with the engine heated up. rpm (If top rpm is not achieved contact Solé to inspect propeller dimensions). Engine rpm with engine idling and clutch out rpm Engine output and inverter operation. Verify operation of the Trolling valve, if applicable. Engine temperature and oil pressure. Information for the Owner Notes V/x Delivery of the instrucions manual and engine-related documents.

Review of the engine instrucions manual.

Report the first revision date.

functions.

Study the instruments panel functions and the engine control

Report the maintenance schedule indicated in the manuals.

Declaration of conformity for recreational Craft Propulsion Engines Side Diesel



Section 13 - Declaration of conformity for recreational Craft Propulsion Engines



Marine engines - Gensets - Accesories

Declaration of Conformity for Recreational Craft Propulsion Engines (inboard engines and stern drive engines without integral exhaust) with the requirements of Directive 2013/53/EU

Name of engine	manufacturer:	SOLÉ, S.A.				
Address:	Ctra. C-243b, Km. 2	•				
Town:	Martorell	Post Code:	08760	Country:	Spain	
Name of Author	ised Representative:					
Address:		-				
Town:		Post Code:		Country:		
Name of Notifie	d Body for exhaust emission a	ssessment:		EUROCO	NTROL	
Address:	Santa Engracia, 56					
Town:	Madrid	Post Code:	28010	Country:	Spain	
ID Number:	0057	_				
Conformity asse exhaust emissio	ssment module used for ns:	[✓ B+C/C1	B+D	B+E B+F G H	
or engine type-a	pproved according to:		Directive 97	7/68/EC	EC Regulation No 595/2009	
Other Communi	ty Directives applied:					
	.,					
DESCRIPTION	I OF PROPULSION ENGIN	IE TYPE(S)				
Main Propulsion	n ExhaustType:	Comi	bustion Type:		Combustion cycl	le:
☐ With integra		✓	Internal combi	ustion Diesel		
	egral exhaust		Internal combi			
	-8		Other	,		
ı	DENTIFICATION OF ENG	ine(s) cov	ERED BY THI	S DECLARA	ATION OF CONFORMITY	
Name of engin	e model or engine family:	Unique eng	ine identificat	ion	EC Type–examination certificate	or
		number(s)	or engine fami	ily code(s)	type-approval certificate numbe	r
NAINI 62/6					46 00 BCD 664 000065 /6 B	
MINI-62/G					16-09-RCD-SSA-G00265/C-Rev. 2	_
						\dashv
						$\overline{}$
	ional craft propulsion engine(•	•		r. I declare on behalf of the manufactonts specified in Article 4 (1) and Annex	
Name / function	: Sr. Enrique Solé Matas		Signature a	nd title:	Chief Executive Officer	
engine manufactu	he person empowered to sign on rer or his authorised representati is authorised representative)			alent marking)	(Suble	
Date and place of	of issue: (dd/mm/yyyy),		17/01/2022	2		





Essential requirements reference to relevant articles in Annex IB & IC of the Directive)	Harmonised standards Full Application	Harmonised standards Partial application, see tech. File	Other reference documents 1 Full Application	Other reference documents Partial Application , see tech. File	Other proof of conformity See technical. File	Specify the harmonised 2 standards or other reference documents used (with year of publication like "EN ISO 8666:2002")
		Tick only	one box	per line	!	All lines right of ticked boxes must be filled in
Annex I.A - Design and Construction of Products						
Design and Construction of Products (Annex I A.)				✓		Chapter 1.1 (Owner's Manual)
Annex I.B – Exhaust Emissions						
Propulsion Engine Identification (Annex I B.1)				✓		Chapter 1
Exhaust Emission Requirements (Annex I B. 2)	7					EN ISO 8178-1:1996
Durability (Annex I B.3)				7		Chapter 7.1 (Owner's Manual)
Owner's manual (Annex I B.4)			7			
Annex I.C – Noise Emissions	See Declaration of Conformity of the recreational craft in which the engine installed				5 ,, ,	

- 1. Annex I.C Noise Emissions
- 2.Standards published in EU Official Journal





Marine engines - Gensets - Accesories

Declaration of Conformity for Recreational Craft Propulsion Engines (inboard engines and stern drive engines without integral exhaust) with the requirements of Directive 2013/53/EU

Name of engine ma	nufacturer:	SOLÉ, S.A.					
Address:	Ctra. C-243b, Km. 2						
Town:	Martorell	Post Code:	08760	Country:		Spain	
Name of Authorise	d Representative:						
Address:							
Town:		Post Code:		Country:			
Name of Notified B	ody for exhaust emission a	ssessment:		THE VEH	ICLE CERTIFICATI	ON AGENCY	
Address:	1 The Eastgate Office Cer	ntre					
Town:	Bristol	Post Code:	BS5 6XX	Country:	U	nited Kindom	
ID Number:	1580	_					
Conformity assessn exhaust emissions:	nent module used for	[✓ B+C/C1	B+D	B+E B+F	☐G ☐H	
or engine type-app	roved according to:		☐ Directive 97	7/68/EC	EC Regulation	on No 595/2009	
Other Community I	Directives applied:						
.,							
DESCRIPTION O	F PROPULSION ENGIN	IE TYPE(S)					
Main Propulsion Ex	khaustType:	Com	bustion Type:			Combustion cycle:	
. With integral e		√	Internal combu	istion Diesel	l (CI)	2 stroke	
✓ With integral c			Internal combu			√ 4 stroke	
Tritiloge integ.	ar canadat		Other		. (6.7	. 555	
IDE	NTIFICATION OF ENG	INE(S) COV	ERED BY THI	S DECLAR	ATION OF COM	NFORMITY	
Name of engine r	nodel or engine family:	Unique eng	ine identificati	ion	EC Type–exam	ination certificate or	٦
		_	or engine fami		1	certificate number	
MINI-74 (S4S-DPB)					e11*97/68JA*20	004/26*0787*00	7
SM-82 (S4S_DTDP2)				e11*97/68JA*20	004/26*0782*00	7
SM-94 (S4S-DTDPA	A2)				e11*97/68JA*20	004/26*0781*00	
							_
							4
							4
	conformity is issued under al craft propulsion engine(s EU.						
Name / function:	Sr. Enrique Solé Matas		Signature ar	nd title:	Chief Executive	Officer	
engine manufacturer	person empowered to sign on or his authorised representati uthorised representative)		(or an equiva e	lent marking)	C	Zuhl)	_
Date and place of is	ssue: (dd/mm/yyyy),		08/05/2019)			





Essential requirements reference to relevant articles in Annex IB & IC of the Directive)	Harmonised standards Full Application	Harmonised standards Partial application, see tech. File	Other reference documents 1 Full Application	Other reference documents Partial Application , see tech. File	Other proof of conformity See technical. File	Specify the harmonised 2 standards or other reference documents used (with year of publication like "EN ISO 8666:2002")
		Tick only	one box	c per line	!	All lines right of ticked boxes must be filled in
Annex I.A - Design and Construction of Products						
Design and Construction of Products (Annex I A.)				✓		Chapter 1.1 (Owner's Manual)
Annex I.B – Exhaust Emissions						
Propulsion Engine Identification (Annex I B.1)				7		Chapter 1
Exhaust Emission Requirements (Annex I B. 2)	V					EN ISO 8178-1:1996
Durability (Annex I B.3)				7		Chapter 7.1 (Owner's Manual)
Owner's manual (Annex I B.4)			✓			
Annex I.C – Noise Emissions	See Declaration of Conformity of the recreational craft in which the engine(s installed					

- 1. Annex I.C Noise Emissions
- 2.Standards published in EU Official Journal





Marine engines - Gensets - Accesories

Declaration of Conformity for Recreational Craft Propulsion Engines (inboard engines and stern drive engines without integral exhaust) with the requirements of Directive 2013/53/EU

Name of engine ma	anufacturer:	SOLÉ, S.A.				
Address:	Ctra. C-243b, Km. 2					
Town:	Martorell	Post Code:	08760	Country	:	Spain
Name of Authorise	ed Representative:					
Address:						
Town:		Post Code:		Country		
Name of Notified E	Body for exhaust emission a	ssessment:		THE VEH	IICLE CERTIFICAT	ION AGENCY
Address:	1 The Eastgate Office Cer	ntre				
Town:	Bristol	Post Code:	BS5 6XX	Country	:	Jnited Kindom
ID Number:	1580					
Conformity assessi exhaust emissions:	ment module used for		√ B+C/C1 [B+D	B+E B+F	☐G ☐H
or engine type-app	proved according to:		Directive 9	7/68/EC	EC Regulati	ion No 595/2009
Other Community	Directives applied:					
•						
DESCRIPTION C	OF PROPULSION ENGIN	IE TYPE(S)				
Main Propulsion E	xhaustType:	Com	bustion Type:			Combustion cycle:
☐ With integral €	exhaust	✓	Internal comb	ustion, Diese	I (CI)	2 stroke
✓ Without integ			Internal comb	ustion, Petro	l (SI)	√ 4 stroke
			Other			
IDE	ENTIFICATION OF ENG	INE(S) COV	ERED BY TH	IS DECLAR	ATION OF CO	NFORMITY
Name of engine	model or engine family:	1	ine identificat or engine fam			nination certificate or I certificate number
SM-105/L (S6S-DPF	2)				011*07/6910*3	2004/26*0787*00
3NI-103/L (303-DPI) 				e11 97/00JA 2	:004/26*0787*00
	conformity is issued under al craft propulsion engine(s 'EU.		-			
Name / function:	Sr. Enrique Solé Matas		Signature a	and title:	Chief Executive	Officer
engine manufacturer	person empowered to sign on or his authorised representati authorised representative)		· · · · · ·	alent marking)		Bu he
Date and place of i	ssue: (dd/mm/yyyy),		08/05/201	9		





Essential requirements reference to relevant articles in Annex IB & IC of the Directive)	Harmonised standards Full Application	Harmonised standards Partial application, see tech. File	Other reference documents 1 Full Application	Other reference documents Partial Application , see tech. File	Other proof of conformity See technical. File	Specify the harmonised 2 standards or other reference documents used (with year of publication like "EN ISO 8666:2002")
		Tick only	one bo	c per line	!	All lines right of ticked boxes must be filled in
Annex I.A - Design and Construction of Products						
Design and Construction of Products (Annex I A.)				✓		Chapter 1.1 (Owner's Manual)
Annex I.B – Exhaust Emissions						
Propulsion Engine Identification (Annex I B.1)				\		Chapter 1
Exhaust Emission Requirements (Annex I B. 2)	7					EN ISO 8178-1:1996
Durability (Annex I B.3)				7		Chapter 7.1 (Owner's Manual)
Owner's manual (Annex I B.4)			7			
Annex I.C – Noise Emissions	See Declaration of Conformity of the recreational craft in which the engine(s) has (ha installed				5 , , , ,	

- 1. Annex I.C Noise Emissions
- 2.Standards published in EU Official Journal



Maintenance log



Section14 - Maintenance log

DATE	HOURS	DESCRIPTION	SERVICE NAME
	1		

Maintenance log



DATE	HOURS	DESCRIPTION	SERVICE NAME
DATE	HOOKO	Discontinuon	SERVISE IVANE



MARINE DIESEL ENGINES - GENSETS - PROPELLERS - ACCESSORIES

C-243 b, km $2\cdot08760$ Martorell (Barcelona) Tel. +34 93 775 14 00 · Fax +34 93 775 30 13 www.solediesel.com · info@solediesel.com

Follow us:









© Copyright 2019 Solé Diesel. All rights reserved. Texts and specifications are subject to change without notice and without any obligation or liability whatsoever.



U_CTMT62G105L_EN Revision 1 07/2022